

Full Contents

Section 1: Overview Essentials

| | | |
|------------|---|-----------|
| 1.1 | Introduction | 3 |
| | Learning InRoads | 3 |
| | Basic Rules | 3 |
| | How to Use This Guide | 4 |
| | Section Breakdown | 5 |
| | <i>Section 1: Overview Essentials</i> | 5 |
| | <i>Section 2: Production Essentials</i> | 5 |
| | <i>Glossary</i> | 5 |
| | <i>Index</i> | 5 |
| | What's in a Chapter? | 5 |
| | Font Conventions | 6 |
| | <i>Italic</i> | 6 |
| | <i>Bold</i> | 6 |
| | <i>Bold and Italic</i> | 7 |
| | <i>Small Caps</i> | 7 |
| | <i>Underlined Small Caps</i> | 7 |
| | How to Use the CD | 7 |
| | Files on CD-ROM | 7 |
| | <i>Training Folders</i> | 7 |
| | <i>Training Files</i> | 8 |
| | <i>Chapter Files</i> | 10 |
| | Other CD Content | 10 |
| | Software Information | 10 |
| | AutoCAD versus MicroStation | 10 |
| | Version Compatibility | 11 |
| | Software File Paths | 12 |
| 1.2 | Orientation to InRoads | 13 |
| | Chapter Prerequisites | 14 |
| | The Bigger Picture | 14 |
| | InRoads versus CAD | 15 |
| | <i>The CAD Platform</i> | 15 |
| | <i>File Types</i> | 15 |
| | <i>InRoads and CAD</i> | 16 |
| | The InRoads Interface | 17 |
| | The Menu Bar | 17 |
| | The Workspace Bar | 18 |
| | The Feedback Pane | 18 |
| | Status Bar | 19 |
| | Toolbars | 19 |
| | The Surface Model | 21 |
| | Surface Origins | 21 |
| | Intelligent Models | 22 |
| | Surface Display | 24 |

| | |
|-------------------------------------|-----------|
| Geometry | 25 |
| COGO Points | 25 |
| Horizontal Alignments | 25 |
| Vertical Alignments | 27 |
| Event Points | 27 |
| Profiles | 28 |
| Annotation | 29 |
| Typical Sections | 30 |
| Backbone | 30 |
| Cut and Fill Conditions | 30 |
| Layers and Components | 31 |
| Surface Intelligence | 32 |
| Roadway Models | 32 |
| Express Modeler | 33 |
| Roadway Designer | 33 |
| Defining the Roadway | 34 |
| Running the Modeler | 34 |
| Superelevation | 36 |
| Cross Sections | 38 |
| Custom Cross Sections | 39 |
| Cross Section Viewer | 40 |
| Annotation | 40 |
| Cross Section Editing | 40 |
| Volumes | 41 |
| Triangle Volume | 41 |
| Grid Volume | 41 |
| End-Area Volume | 42 |
| Reporting | 42 |
| XML Reporting | 43 |
| Preferences | 45 |
| Tools> Options | 46 |
| The Managers | 46 |
| Symbology Manager | 47 |
| Features - Style Manager | 48 |
| Geometry - Style Manager | 50 |
| Preference Manager | 51 |
| The Locks | 52 |
| Pen and Pencil | 52 |
| Locate Lock | 53 |
| Snap Lock | 53 |
| Station Lock | 54 |
| Report Lock | 55 |
| Feature Filter | 55 |
| InRoads Support | 56 |
| InRoads Help File | 57 |
| Training | 57 |
| Bentley | 58 |
| Consultants | 58 |
| Chapter Challenge | 58 |
| Quiz Questions | 58 |
| 1.3 Sample Project Defined | 61 |
| Preliminary Design Statement | 61 |
| Project Design Criteria | 61 |

| | |
|---|-----------|
| Scope of Work Details | 62 |
| <i>Typical Sections</i> | 63 |
| <i>Concept Sketches</i> | 64 |
| <i>Design Criteria</i> | 66 |
| <i>Project Vicinity Map</i> | 68 |
| 1.4 Getting Going Now! | 69 |
| Chapter Prerequisites | 70 |
| Files Needed | 70 |
| Hands On—Get Going Now! | 71 |
| Hands-On—An Introduction | 71 |
| Orientation | 71 |
| Loading the Training Files | 75 |
| <i>Preparing and Opening InRoads</i> | 75 |
| <i>Project Defaults</i> | 76 |
| <i>Creating a New Project Default Configuration</i> | 79 |
| <i>Opening the Data</i> | 80 |
| Lock Settings | 81 |
| CAD File Preparation | 81 |
| Surface Review and Display | 82 |
| <i>Perimeter</i> | 82 |
| <i>Contours</i> | 83 |
| <i>Triangles</i> | 84 |
| <i>Update 3-D/Plan Surface Display</i> | 85 |
| <i>Surface Properties</i> | 87 |
| <i>Feature Properties</i> | 88 |
| <i>View Features</i> | 89 |
| Horizontal Geometry File Creation | 92 |
| <i>The Geometry Project</i> | 92 |
| <i>Horizontal Alignment</i> | 94 |
| <i>Vertical Alignment</i> | 95 |
| Horizontal Geometry Workspace Bar Review | 96 |
| <i>Workspace Bar Shortcuts - Review</i> | 97 |
| <i>Workspace Bar Shortcuts - View</i> | 98 |
| <i>View Stationing</i> | 100 |
| <i>Alignment Stationing</i> | 101 |
| <i>Horizontal Annotation</i> | 103 |
| Profiling | 106 |
| <i>Create Profile</i> | 107 |
| Vertical Geometry Viewing | 112 |
| <i>View Vertical</i> | 112 |
| <i>View Vertical Annotation</i> | 113 |
| Typical Sections | 114 |
| <i>Templates</i> | 115 |
| Roadway Modeling | 118 |
| <i>Express Modeler</i> | 118 |
| <i>Running the Express Modeler</i> | 121 |
| Creating Cross Sections | 125 |
| <i>Create Cross Sections</i> | 125 |
| <i>Cross Section Viewer</i> | 128 |
| Express Modeler and Cross Section Repetition | 130 |
| <i>Express Modeler Revisited</i> | 130 |
| <i>Cross Sections Revisited</i> | 131 |
| End-Area Volumes | 132 |

| | |
|--------------------------------|-----|
| <i>End-Area Volumes</i> | 132 |
| Chapter Challenge | 136 |
| Additional Exercises | 136 |
| Quiz Questions | 136 |

Section 2: Production Essentials

| | |
|---|-----|
| 2.1 Starting Up | 141 |
| Chapter Prerequisites | 141 |
| Knowledge Prerequisites | 141 |
| Data Prerequisites | 141 |
| Files Needed | 141 |
| Hands On—Starting Up | 142 |
| Selecting a CAD Platform | 142 |
| Starting InRoads | 143 |
| <i>InRoads Versus CAD</i> | 143 |
| The InRoads Interface | 145 |
| <i>The Menu Bar</i> | 145 |
| <i>The Workspace Bar</i> | 146 |
| <i>Workspace Bar Shortcuts</i> | 148 |
| <i>Active Data</i> | 149 |
| <i>Repositioning</i> | 150 |
| <i>The Feedback Pane</i> | 151 |
| Toolbars | 152 |
| <i>Standard Issue Toolbars</i> | 152 |
| <i>Modifying a Toolbar</i> | 153 |
| <i>Restoring Toolbar Defaults</i> | 154 |
| <i>Building a Custom Toolbar</i> | 155 |
| <i>Exporting and Importing Toolbars</i> | 156 |
| Project Defaults | 157 |
| <i>Creating a New Configuration</i> | 157 |
| Application Add-ins | 159 |
| Saving InRoads Data | 160 |
| Bentley Embedded Help | 160 |
| Exiting InRoads | 162 |
| Chapter Challenge | 163 |
| Additional Exercises | 163 |
| <i>Variable Manager</i> | 164 |
| Quiz Questions | 166 |
| 2.2 Settings, Styles and Symbology | 167 |
| Chapter Prerequisites | 167 |
| Knowledge Prerequisites | 167 |
| Data Prerequisites | 167 |
| Files Needed | 168 |
| Hands on — The Managers | 168 |
| <i>Managers Overview</i> | 169 |
| Using the Symbology Manager | 170 |
| <i>Using Named Symbology - Part 1</i> | 172 |
| <i>Using Named Symbology - Part 2</i> | 174 |
| <i>Using Named Symbology - Part 3</i> | 175 |
| Introduction to Intelligent DTM's | 176 |
| Style Manager - DTM Features | 176 |
| <i>Style - Surface Display</i> | 179 |

| | |
|--|------------|
| Style Manager - Geometry | 179 |
| <i>Geometry Style - Details</i> | 182 |
| Creating a New Geometry Style | 185 |
| <i>General Information</i> | 186 |
| <i>Assigning Symbology</i> | 186 |
| <i>Assigning New Symbology</i> | 189 |
| <i>Defining the Settings</i> | 192 |
| Geometry Styles - Assigning | 193 |
| Preferences | 195 |
| <i>Preference Manager</i> | 197 |
| <i>Changing the Default Preference</i> | 198 |
| <i>Preferences Expanded</i> | 199 |
| Chapter Challenge | 203 |
| Additional Exercises | 203 |
| Quiz Questions | 204 |
| 2.3 Surface Essentials | 207 |
| Chapter Prerequisites | 207 |
| Knowledge Prerequisites | 207 |
| Data Prerequisites | 207 |
| Files Needed | 207 |
| Hands On—Surface Essentials | 208 |
| Getting Started with Surfaces | 208 |
| <i>Starting Checks</i> | 208 |
| What is a DTM anyway? | 209 |
| DTM Basics | 210 |
| <i>Surface—New</i> | 210 |
| <i>The Basic DTM Point Types</i> | 211 |
| <i>Surface Properties</i> | 212 |
| The Existing Surface | 213 |
| <i>Feature Properties</i> | 213 |
| <i>The Three Feature Characteristics</i> | 214 |
| Introduction to the Tools | 215 |
| <i>The Pencil Setting</i> | 215 |
| <i>The Pen Setting</i> | 215 |
| Surface Viewing | 216 |
| <i>Perimeter</i> | 216 |
| <i>Contours</i> | 216 |
| <i>Triangles</i> | 216 |
| <i>Update 3-D/Plan Surface Display</i> | 217 |
| <i>View Features</i> | 218 |
| Text Import Wizard - ASCII DTM Data | 219 |
| <i>Confirming Data Import</i> | 229 |
| <i>Processing Imported Surface Data</i> | 229 |
| <i>Viewing Imported Surface Data</i> | 230 |
| <i>Surface Import from Graphics, Utilities</i> | 231 |
| <i>Drape Surface, Utilities</i> | 234 |
| <i>Surface Import From Graphics, Contours</i> | 237 |
| DTM Data Viewing | 240 |
| <i>Triangulation</i> | 241 |
| <i>Triangulate Surface</i> | 242 |
| <i>Saving Surfaces</i> | 244 |
| Chapter Challenge | 246 |
| Additional Exercises | 246 |

| | |
|---|------------|
| Quiz Questions | 247 |
| 2.4 Horizontal Geometry | 249 |
| Chapter Prerequisites | 249 |
| Knowledge Prerequisites | 249 |
| Data Prerequisites | 250 |
| Files Needed | 250 |
| Hands On—Geometry | 250 |
| Project Scope Orientation | 250 |
| The Geometry Project File | 251 |
| <i>Opening Existing Geometry</i> | 251 |
| Existing Geometry—Examination | 252 |
| <i>Workspace Bar Assessment</i> | 252 |
| <i>Feedback Pane Assessment</i> | 253 |
| <i>Viewing Assessment—Preparation</i> | 253 |
| <i>View Horizontal Alignment</i> | 255 |
| <i>Point Symbology</i> | 255 |
| <i>Review Horizontal Alignment</i> | 260 |
| <i>View Stationing</i> | 262 |
| <i>Viewing Assessment - Continued</i> | 263 |
| <i>Review Geometry Points</i> | 264 |
| <i>Horizontal Annotation—Cogo Points</i> | 265 |
| Horizontal Layout Discussion | 268 |
| <i>Layout Methods</i> | 268 |
| <i>Project Orientation</i> | 269 |
| Main Road Layout | 269 |
| Layout Option 1 | 269 |
| <i>Creating Geometry</i> | 270 |
| <i>Saving Geometry</i> | 271 |
| <i>Horizontal Curve Set—Add PI</i> | 272 |
| <i>PI—Precision Key-in</i> | 273 |
| <i>Review/Save Horizontal</i> | 274 |
| <i>Horizontal Curve Set—Define Curve</i> | 275 |
| <i>Defining the Beginning Station</i> | 277 |
| <i>View Stationing</i> | 278 |
| Alignment Completion | 279 |
| <i>Import Geometry from Graphics</i> | 280 |
| <i>Completion Steps</i> | 282 |
| Chapter Challenge | 283 |
| Additional Exercises | 283 |
| Layout Option 2 | 283 |
| <i>Create/Edit Alignment by Cogo Points</i> | 283 |
| <i>Horizontal Alignment Annotation</i> | 285 |
| <i>Copy Geometry</i> | 287 |
| <i>Viewing Geometry</i> | 288 |
| <i>Delete Horizontal PI</i> | 289 |
| <i>Delete Horizontal Element</i> | 290 |
| <i>Alignment Discontinuity Check</i> | 294 |
| <i>Add Horizontal Free Curve</i> | 295 |
| <i>Defining the Beginning Station</i> | 297 |
| <i>View Stationing</i> | 297 |
| Layout Option 3 | 298 |
| <i>Add Fixed Line</i> | 299 |
| <i>Add Horizontal Free Curve</i> | 301 |

| | |
|--|------------|
| <i>Defining the Beginning Station</i> | 302 |
| <i>View Stationing</i> | 302 |
| <i>Copy Geometry</i> | 302 |
| Side Road Centerline Layout | 304 |
| Horizontal Regression | 304 |
| <i>Regression Deviation Check</i> | 304 |
| <i>Side Road Regression Check</i> | 308 |
| Quiz Questions | 309 |
| 2.5 Profiling | 311 |
| Chapter Prerequisites | 312 |
| Knowledge Prerequisites | 312 |
| Data Prerequisites | 312 |
| Files Needed | 312 |
| Hands On—Profiling | 313 |
| Creating Profiles | 313 |
| Updating the Profile Overview | 315 |
| Updating the Profile | 318 |
| Profiles—Other Commands | 319 |
| Chapter Challenge | 320 |
| Additional Exercises | 320 |
| Create Profile Settings | 321 |
| Create Profile - General Leaf | 321 |
| <i>Set Name</i> | 321 |
| <i>Direction</i> | 321 |
| <i>Exaggeration</i> | 321 |
| <i>Surface Symbology</i> | 322 |
| Create Profile - Source Leaf | 324 |
| Create Profile - Controls Leaf | 324 |
| <i>Limits</i> | 325 |
| <i>Window Clearance</i> | 325 |
| Create Profile - Offsets Leaf | 326 |
| Create Profile - Include Leaf | 327 |
| <i>Crossing/Projected Features</i> | 327 |
| <i>Styles and Display</i> | 327 |
| <i>Bandwidth</i> | 329 |
| Create Profile - Symbology | 330 |
| Quiz Questions | 331 |
| 2.6 Vertical Geometry | 333 |
| Chapter Prerequisites | 334 |
| Knowledge Prerequisites | 334 |
| Data Prerequisites | 334 |
| Files Needed | 334 |
| Hands On—Vertical Geometry | 335 |
| Vertical Layout Discussion | 336 |
| <i>Layout Methods</i> | 336 |
| <i>Vertical Alignment Layout Prerequisites</i> | 336 |
| <i>The Project Orientation</i> | 337 |
| Main Road Layout | 338 |
| Layout Option 1—Import from DTM | 338 |
| <i>Import Vertical from Surface</i> | 339 |
| <i>View and Review</i> | 340 |
| <i>View Vertical Annotation</i> | 341 |
| <i>Matching or Paralleling Existing Grade</i> | 343 |

| | |
|---|------------|
| <i>Saving Vertical Alignments</i> | 343 |
| Creating New Vertical Geometry | 343 |
| Layout Option 2—Vertical Curve Set | 344 |
| <i>VPI—Precision Key-in</i> | 345 |
| <i>Vertical Curve Set Tools</i> | 345 |
| <i>Preparation</i> | 345 |
| <i>VPI Dynamics</i> | 346 |
| <i>Vertical Curve Set—Add PI</i> | 346 |
| <i>Review Alignment</i> | 348 |
| <i>Adding More VPIs</i> | 348 |
| <i>Vertical Curve Set—Move PI</i> | 349 |
| <i>Vertical Curve Set—Insert PI</i> | 351 |
| <i>Vertical Curve Set—Define Curve</i> | 352 |
| <i>Move Curve PI</i> | 353 |
| <i>Completion Notes</i> | 354 |
| <i>Vertical Alignment Annotation</i> | 354 |
| Chapter Challenge | 355 |
| Additional Exercises | 355 |
| <i>Side Road Vertical Layout</i> | 355 |
| <i>Vertical Alignment Layout Option 1</i> | 355 |
| <i>Previous Chapter Challenge Work</i> | 355 |
| Layout Option 3—Vertical Element | 355 |
| <i>Update Profile</i> | 357 |
| <i>Element Command Overview</i> | 357 |
| <i>Vertical Starting Point</i> | 358 |
| <i>Add Fixed Vertical Line</i> | 360 |
| <i>Add Fixed Vertical Line</i> | 362 |
| <i>Add Free Vertical Curve</i> | 364 |
| <i>Add Fixed Vertical Curve</i> | 365 |
| <i>Vertical Alignment Discontinuity Check</i> | 366 |
| <i>Add Floating Vertical Line</i> | 367 |
| <i>Add Free Vertical Curve</i> | 368 |
| <i>Vertical Discontinuity Check</i> | 369 |
| <i>Add Floating Vertical Line</i> | 369 |
| <i>Upcoming Vertical Assessment</i> | 371 |
| <i>Copy Elements</i> | 372 |
| <i>Add Free Vertical Curve</i> | 373 |
| <i>Add Fixed Vertical Line</i> | 374 |
| <i>Add Free Vertical Curve</i> | 375 |
| <i>Vertical Completion Checks</i> | 375 |
| <i>Vertical Alignment Annotation</i> | 376 |
| Quiz Questions | 376 |
| 2.7 Typical Sections | 379 |
| Chapter Prerequisites | 380 |
| Knowledge Prerequisites | 380 |
| Data Prerequisites | 380 |
| Files Needed | 380 |
| Hands On—Typical Sections | 381 |
| Creating a Template Library | 381 |
| Opening a Template Library | 384 |
| Reviewing a Template Library | 384 |
| Viewing Templates | 387 |
| <i>View Controls</i> | 389 |

| | |
|---|------------|
| Styles and the Intelligent DTM | 390 |
| Components | 392 |
| Components Expanded | 394 |
| Template Review | 395 |
| <i>Template CAD Display</i> | 397 |
| <i>Template Layers</i> | 400 |
| Component Constraints | 403 |
| <i>More on Constraints</i> | 405 |
| New Template #1 | 406 |
| <i>New Template Placeholder</i> | 406 |
| <i>Template Section Details</i> | 407 |
| <i>Drag and Drop Insertion Point</i> | 408 |
| <i>Template Options</i> | 409 |
| <i>Last Minute Settings</i> | 410 |
| <i>Dragging and Dropping Components</i> | 411 |
| <i>Last Edit Undo / Redo</i> | 413 |
| <i>Component Mirroring</i> | 413 |
| <i>Template #1 Completion</i> | 416 |
| <i>Adding Cut / Fill Slopes</i> | 418 |
| <i>Component Merging</i> | 421 |
| <i>Constraint Release</i> | 424 |
| <i>End Condition Testing</i> | 428 |
| Create Template Command Summary | 429 |
| New Template #2 | 430 |
| <i>Saving Templates</i> | 430 |
| Additional Template Topics | 431 |
| <i>Preparation</i> | 431 |
| <i>Add Details Step by Step</i> | 431 |
| <i>Multiple Passes</i> | 432 |
| <i>Independent Control Notes</i> | 432 |
| <i>Copy Typical Sections</i> | 433 |
| Chapter Challenge | 434 |
| Additional Exercises | 434 |
| <i>Template Basics Checklist</i> | 435 |
| Component Creation | 436 |
| Simple Components | 436 |
| <i>Preparation</i> | 436 |
| <i>Construction and Placement</i> | 439 |
| <i>Component Properties</i> | 442 |
| <i>Point Properties</i> | 443 |
| <i>Using a Simple Component</i> | 446 |
| <i>Simple Component - Template Review</i> | 449 |
| Simple Components Continued | 452 |
| <i>Template Construction</i> | 455 |
| Template Points - Names | 457 |
| Constrained Component #1 | 460 |
| <i>Component Curb Details</i> | 461 |
| <i>Component Construction</i> | 462 |
| <i>Component Review</i> | 466 |
| Unconstrained Components | 467 |
| <i>Unconstrained Component #2</i> | 470 |
| Component Construction | 471 |
| <i>Bike Path / Walkway</i> | 471 |
| End Conditions | 472 |

| | |
|--|------------|
| <i>Fill Slope Creation</i> | 472 |
| <i>Set Dynamic Origin</i> | 477 |
| <i>Reset Dynamic Origin</i> | 479 |
| <i>Dynamic Origin Alert</i> | 479 |
| <i>Cut Slope Creation</i> | 480 |
| Building Template #1 | 481 |
| <i>Template Drag and Drop</i> | 482 |
| <i>End Condition Testing</i> | 484 |
| <i>End Condition #3</i> | 487 |
| <i>Add Additional End Condition</i> | 489 |
| <i>End Condition Re-Test</i> | 489 |
| Building Template #2 | 490 |
| Merging Components | 490 |
| Component Summary | 491 |
| <i>Component Types</i> | 491 |
| <i>Terminology</i> | 491 |
| <i>Component Concept #1</i> | 492 |
| More on Point Controls | 492 |
| Create Your Own | 493 |
| Quiz Questions | 493 |
| 2.8 Corridor Modeling | 495 |
| Chapter Prerequisites | 496 |
| Knowledge Prerequisites | 496 |
| Data Prerequisites | 496 |
| Files Needed | 496 |
| Hands On—Corridor Modeling | 496 |
| Opening Earlier Data | 497 |
| New Roadway Design File | 497 |
| Saving the Roadway Design File | 498 |
| The Project File | 499 |
| Modeling Basics | 502 |
| <i>Prerequisites</i> | 502 |
| The Roadway Designer | 502 |
| <i>Menu Commands</i> | 502 |
| <i>Corridor Management</i> | 504 |
| Project Scope | 505 |
| Adding Template Drops | 507 |
| <i>Continuing Template Drops</i> | 509 |
| End Condition Exceptions | 510 |
| Saving the Roadway Design File | 512 |
| Corridor Review | 513 |
| <i>Transition Bands</i> | 514 |
| <i>Connecting Transition #1 Points</i> | 517 |
| <i>Connecting Transition #2 Points</i> | 521 |
| Pre-Processing the Corridor | 522 |
| Create Surface | 524 |
| <i>Name and Preference</i> | 525 |
| <i>New Surfaces for Each Corridor</i> | 526 |
| <i>Empty Design Surface</i> | 526 |
| <i>Add Exterior Boundary</i> | 527 |
| <i>Densify Curves</i> | 527 |
| <i>Triangulate</i> | 527 |
| <i>Create Surface(s) from</i> | 528 |

| | |
|---|------------|
| <i>Add Transverse Features</i> | 528 |
| <i>Display Features in Plan View</i> | 529 |
| <i>Final Set-up</i> | 529 |
| <i>Creating the Design Surface</i> | 530 |
| <i>Surface Properties</i> | 532 |
| <i>Saving the Design Surface</i> | 533 |
| <i>Viewing Roadway Features</i> | 534 |
| <i>Updating the Project File</i> | 536 |
| Chapter Challenge | 538 |
| <i>Additional Exercises</i> | 538 |
| <i>Superelevation Basics</i> | 539 |
| <i>Fundamentals of Superelevation</i> | 539 |
| <i>Superelevation Slope Rate</i> | 540 |
| <i>Superelevation Transition Locations</i> | 541 |
| <i>InRoads Superelevation</i> | 542 |
| <i>AASHTO Wizard - Step 1, Criteria</i> | 544 |
| <i>Rate Calculator</i> | 546 |
| <i>AASHTO Wizard - Step 1 Revisited</i> | 550 |
| <i>AASHTO Wizard - Step 2, Definitions</i> | 552 |
| <i>AASHTO Wizard - Step 2 Revisited</i> | 556 |
| <i>AASHTO Wizard - Step 3, Controls</i> | 559 |
| <i>Point Controls</i> | 562 |
| <i>Deleting Conflicting Point Controls</i> | 566 |
| <i>Viewing the Superelevation</i> | 567 |
| <i>Editing the Superelevation - Rate</i> | 570 |
| <i>Editing the Superelevation - Transitions</i> | 574 |
| <i>Superelevation Rollover Locks</i> | 576 |
| <i>Superelevation Report</i> | 582 |
| <i>Creating the Surface DTM</i> | 584 |
| <i>Viewing the Superelevation Diagram</i> | 586 |
| <i>Superelevation Design Complexities</i> | 593 |
| <i>Use of Spirals</i> | 593 |
| <i>Various Superelevation Related Tips</i> | 594 |
| <i>Working with Superelevation Alternatives</i> | 594 |
| <i>Superelevation and Alignment Adjustments</i> | 595 |
| <i>Superelevation and Compound Curves Note</i> | 595 |
| <i>Quiz Questions</i> | 595 |
| 2.9 Cross Sections | 597 |
| Chapter Prerequisites | 597 |
| <i>Knowledge Prerequisites</i> | 597 |
| <i>Data Prerequisites</i> | 598 |
| <i>Files Needed</i> | 598 |
| Hands On—Cross Sections | 598 |
| <i>Creating Cross Sections</i> | 600 |
| <i>Cross Section Viewer</i> | 602 |
| <i>Adding and Displaying New Features</i> | 602 |
| <i>Symbology Manager</i> | 603 |
| <i>Style Manager</i> | 605 |
| <i>Adding Geometry to the DTM</i> | 606 |
| <i>Feature Properties</i> | 609 |
| <i>Drape Surface</i> | 609 |
| <i>Updating the Cross Sections Overview</i> | 611 |
| <i>Styles and Cross Sections</i> | 613 |

| | |
|--|------------|
| Updating the Cross Sections | 614 |
| <i>Display On</i> | 614 |
| <i>Refreshing</i> | 614 |
| <i>Component Updating</i> | 615 |
| Cross Sections—Other Commands | 616 |
| Chapter Challenge | 617 |
| Additional Exercises | 617 |
| Create Cross Section—Settings | 617 |
| <i>Cross Section Interval</i> | 618 |
| <i>Surface Symbology</i> | 621 |
| <i>Use Features Only</i> | 622 |
| Create Cross Sections - Source Leaf | 623 |
| Create Cross Sections—Controls | 623 |
| Create Cross Sections—Include Leaf | 624 |
| <i>Crossing & Projected Features</i> | 624 |
| <i>Components</i> | 625 |
| <i>Styles and Display</i> | 625 |
| <i>Show Features Outside</i> | 625 |
| Create Cross Sections—Symbology | 626 |
| Cross Section Layout | 626 |
| Custom Cross Sections | 628 |
| Quiz Questions | 629 |
| Glossary | 631 |
| Index | 643 |