

Full Contents

Section 1: Overview Essentials

1.1	Introduction	3
	Learning InRoads	3
	Basic Rules	3
	How to Use This Guide	4
	Section Breakdown	5
	<i>Section 1: Overview Essentials</i>	5
	<i>Section 2: Production Essentials</i>	5
	<i>Glossary</i>	5
	<i>Index</i>	5
	What's in a Chapter?	5
	Font Conventions	6
	<i>Italic</i>	6
	<i>Bold</i>	6
	<i>Bold and Italic</i>	7
	<i>Small Caps</i>	7
	<i>Underlined Small Caps</i>	7
	How to Use the CD	7
	Files on CD-ROM	7
	<i>Training Folders</i>	7
	<i>Training Files</i>	8
	<i>Chapter Files</i>	10
	Other CD Content	10
	Software Information	10
	AutoCAD versus MicroStation	10
	Version Compatibility	11
	Software File Paths	11
1.2	Orientation to InRoads	13
	Chapter Prerequisites	14
	The Bigger Picture	14
	InRoads versus CAD	15
	<i>The CAD Platform</i>	15
	<i>File Types</i>	15
	<i>InRoads and CAD</i>	16
	The InRoads Interface	17
	The Menu Bar	17
	The Workspace Bar	18
	The Feedback Pane	18
	Status Bar	19
	Toolbars	19
	The Surface Model	21
	Surface Origins	21
	Intelligent Models	22
	Surface Display	24

Geometry	25
COGO Points	25
Horizontal Alignments	25
Vertical Alignments	27
Superelevation	27
Event Points	28
Profiles	29
Annotation	30
Typical Sections	30
Backbone	31
Cut and Fill Conditions	31
Layers	32
Surface Intelligence	32
Superelevation	32
Roadway Models	32
Express Modeler	33
Roadway Modeler	34
Defining the Roadway	34
Running the Modeler	35
Cross Sections	35
Custom Cross Sections	37
Cross Section Viewer	37
Annotation	38
Cross Section Editing	38
Volumes	38
Triangle Volume	39
Grid Volume	39
End-Area Volume	39
Reporting	40
General and Geometry Reports	40
XML Reporting	42
Preferences	43
Tools> Options	44
The Managers	44
Symbology Manager	44
Feature Style Manager	46
Geometry Style Manager	47
Preference Manager	48
The Locks	49
Write Lock	49
Pen and Pencil	50
Locate Lock	50
Snap Lock	51
Station Lock	52
Report Lock	52
Feature Filter	53
InRoads Support	53
InRoads Help File	54
Training	55
Bentley	55
Consultants	55
Chapter Challenge	55
Quiz Questions	56

1.3	Sample Project Defined	57
	Preliminary Design Statement	57
	Project Design Criteria	57
	Scope of Work Details	58
	<i>Typical Sections</i>	59
	<i>Concept Sketches</i>	60
	<i>Design Criteria</i>	62
	<i>Project Vicinity Map</i>	64
1.4	Getting Going Now!	65
	Chapter Prerequisites	66
	Files Needed	66
	Hands On—Get Going Now!	67
	Hands-On—An Introduction	67
	Orientation	67
	Loading the Training Files	71
	<i>Preparing and Opening InRoads</i>	71
	<i>Project Defaults</i>	72
	<i>Creating a New Project Default Configuration</i>	73
	<i>Opening the Data</i>	74
	Lock Settings	76
	Surface Review and Display	76
	<i>Perimeter</i>	76
	<i>Contours</i>	78
	<i>Triangles</i>	80
	<i>Update 3-D/Plan Surface Display</i>	80
	<i>Surface Properties</i>	82
	<i>Feature Properties</i>	83
	<i>View Features</i>	85
	Horizontal Geometry Review and Display	87
	<i>The Geometry Project</i>	87
	<i>Workspace Bar Shortcuts</i>	91
	<i>View Stationing</i>	92
	<i>Alignment Stationing</i>	93
	<i>Horizontal Annotation</i>	94
	Profiling	96
	<i>Create Profile</i>	97
	Vertical Geometry Viewing	101
	<i>View Vertical</i>	101
	<i>View Vertical Annotation</i>	102
	Typical Sections	103
	<i>Templates</i>	104
	Roadway Modeling	105
	<i>Express Modeler</i>	106
	Creating Cross Sections	113
	<i>Create Cross Sections</i>	113
	<i>Cross Section Viewer</i>	116
	Express Modeler and Cross Section Repetition	117
	<i>Express Modeler Revisited</i>	117
	<i>Cross Sections Revisited</i>	118
	End-Area Volumes	119
	<i>End-Area Volumes</i>	120
	<i>End-Area Volumes Revisited</i>	123
	<i>End-Area Volume Reporting</i>	124

Chapter Challenge	125
Additional Exercises	125
Quiz Questions	125

Section 2: Production Essentials

2.1 Starting Up	129
Chapter Prerequisites	129
Knowledge Prerequisites	129
Data Prerequisites	129
Files Needed	129
Hands On—Starting Up	130
Selecting a CAD Platform	130
Starting InRoads	131
<i>InRoads Versus CAD</i>	131
The InRoads Interface	133
<i>The Menu Bar</i>	133
<i>The Workspace Bar</i>	134
<i>Workspace Bar Shortcuts</i>	136
<i>Active Data</i>	137
<i>Repositioning</i>	138
<i>The Feedback Pane</i>	139
Toolbars	140
<i>Standard Issue Toolbars</i>	140
<i>Modifying a Toolbar</i>	141
<i>Restoring Toolbar Defaults</i>	142
<i>Building a Custom Toolbar</i>	143
<i>Exporting and Importing Toolbars</i>	144
Project Defaults	145
<i>Creating a New Configuration</i>	145
Application Add-ins	147
Saving InRoads Data	147
Bentley Embedded Help	148
Exiting InRoads	149
Chapter Challenge	149
Additional Exercises	149
Quiz Questions	151
2.2 Settings, Styles and Symbology	153
Chapter Prerequisites	153
Knowledge Prerequisites	153
Data Prerequisites	153
Files Needed	154
Hands on — The Managers	154
<i>Managers Overview</i>	155
Using the Symbology Manager	156
<i>Using Named Symbology—Part 1</i>	158
<i>Using Named Symbology—Part 2</i>	160
<i>Using Named Symbology—Part 3</i>	161
Introduction to Intelligent DTMs	162
Feature Style Manager	162
<i>Feature Style—Display</i>	164
Geometry Style Manager	165
<i>Creating a New Geometry Style</i>	167

Preferences	168
<i>Preference Manager</i>	170
<i>Changing the Default Preference</i>	171
<i>Preferences Expanded</i>	172
Chapter Challenge	176
Additional Exercises	176
Quiz Questions	177
2.3 Surface Essentials	179
Chapter Prerequisites	179
Knowledge Prerequisites	179
Data Prerequisites	179
Files Needed	179
Hands On—Surface Essentials	180
Getting Started with Surfaces	180
<i>Starting Checks</i>	180
What is a DTM anyway?	181
DTM Basics	182
<i>Surface—New</i>	182
<i>The Basic DTM Point Types</i>	183
<i>Surface Properties</i>	184
The Existing Surface	185
<i>Feature Properties</i>	185
<i>The Three Feature Characteristics</i>	186
Introduction to the Locks	187
<i>The Write Lock</i>	187
<i>The Pencil Setting</i>	187
<i>The Pen Setting</i>	187
Surface Viewing	188
<i>Perimeter</i>	188
<i>Contours</i>	188
<i>Triangles</i>	188
<i>Update 3-D/Plan Surface Display</i>	189
<i>View Features</i>	190
<i>Surface Import from ASCII</i>	191
<i>Processing Imported Surface Data</i>	196
<i>Viewing Imported Surface Data</i>	197
<i>Surface Import from Graphics, Utilities</i>	198
<i>Drape Surface, Utilities</i>	201
<i>Surface Import From Graphics, Contours</i>	204
Triangulation	207
<i>Triangulate Surface</i>	208
Saving Surfaces	210
Chapter Challenge	212
Additional Exercises	212
Quiz Questions	213
2.4 Horizontal Geometry	215
Chapter Prerequisites	215
Knowledge Prerequisites	215
Data Prerequisites	216
Files Needed	216
Hands On—Geometry	216
Project Scope Orientation	216
The Geometry Project File	217

<i>Opening Existing Geometry</i>	217
Existing Geometry—Examination	218
<i>Workspace Bar Assessment</i>	218
<i>Feedback Pane Assessment</i>	219
<i>Viewing Assessment—Preparation</i>	220
<i>View Horizontal Alignment</i>	221
<i>Point Symbolology</i>	221
<i>Review Horizontal Alignment</i>	224
<i>View Stationing</i>	226
<i>Viewing Assessment - Continued</i>	227
<i>Review Geometry Points</i>	229
<i>Horizontal Annotation—Cogo Points</i>	230
Horizontal Layout Discussion	234
<i>Layout Methods</i>	234
<i>Project Orientation</i>	235
Main Road Layout	235
Layout Option 1	235
<i>Creating Geometry</i>	236
<i>Saving Geometry</i>	237
<i>Horizontal Curve Set—Add PI</i>	238
<i>PI—Precision Key-in</i>	239
<i>Review/Save Horizontal</i>	240
<i>Horizontal Curve Set—Define Curve</i>	241
Layout Option 2	243
<i>Create/Edit Alignment by Cogo Points</i>	243
<i>Horizontal Alignment Annotation</i>	245
<i>Copy Geometry</i>	246
<i>Viewing Geometry</i>	247
<i>Delete Horizontal PI</i>	248
<i>Delete Horizontal Element</i>	250
<i>Alignment Discontinuity Check</i>	253
<i>Add Horizontal Free Curve</i>	254
<i>Defining the Beginning Station</i>	256
<i>View Stationing</i>	257
Layout Option 3	257
<i>Add Fixed Line</i>	258
<i>Add Horizontal Free Curve</i>	260
<i>Defining the Beginning Station</i>	261
<i>View Stationing</i>	261
<i>Copy Geometry</i>	261
Chapter Challenge	263
Additional Exercises	263
<i>Side Road Centerline Layout</i>	263
<i>Regression Deviation Check</i>	263
<i>Side Road Regression Check</i>	267
Quiz Questions	268
2.5 Profiling	269
Chapter Prerequisites	270
Knowledge Prerequisites	270
Data Prerequisites	270
Files Needed	270
Hands On—Profiling	270
Creating Profiles	271

Create Profile—Main tab	272
<i>Surface Symbology</i>	273
Create Profile—Controls Tab	275
<i>Limits</i>	275
<i>Exaggeration</i>	275
<i>Direction</i>	276
<i>Window Clearance</i>	276
Create Profile—Offsets Tab	277
Create Profile—Features Tab	278
<i>Crossing/Projected Features</i>	278
<i>Styles and Display</i>	278
<i>Features—Bandwidth</i>	280
Create Profile—Reports	282
Create Profile—Symbology	283
Updating the Profile Overview	283
Updating the Profile	284
Profiles—Other Commands	286
Chapter Challenge	287
Additional Exercises	287
Quiz Questions	287
2.6 Vertical Geometry	289
Chapter Prerequisites	290
Knowledge Prerequisites	290
Data Prerequisites	290
Files Needed	290
Hands On—Vertical Geometry	290
Vertical Layout Discussion	291
<i>Layout Methods</i>	292
<i>Vertical Alignment Layout Prerequisites</i>	292
<i>The Project Orientation</i>	292
Creating New Vertical Geometry	294
Main Road Layout	295
Layout Option 1—Import from DTM	295
<i>Import Vertical from Surface</i>	296
<i>View and Review</i>	297
<i>View Vertical Annotation</i>	298
<i>Matching or Paralleling Existing Grade</i>	300
<i>Saving Vertical Alignments</i>	300
Layout Option 2—Vertical Curve Set	300
<i>VPI—Precision Key-in</i>	301
<i>Vertical Curve Set Tools</i>	301
<i>Preparation</i>	301
<i>VPI Dynamics</i>	302
<i>Vertical Curve Set – Add PI</i>	302
<i>Review Alignment</i>	304
<i>Adding More VPIs</i>	304
<i>Vertical Curve Set—Move PI</i>	305
<i>Vertical Curve Set – Insert PI</i>	307
<i>Vertical Curve Set—Define Curve</i>	308
<i>Move Curve PI</i>	309
<i>Completion Notes</i>	310
Layout Option 3—Vertical Element	310
<i>Update Profile</i>	312

<i>Element Command Overview</i>	312
<i>Vertical Starting Point</i>	313
<i>Add Fixed Vertical Line</i>	315
<i>Add Fixed Vertical Line</i>	317
<i>Add Free Vertical Curve</i>	319
<i>Add Fixed Vertical Curve</i>	320
<i>Vertical Alignment Discontinuity Check</i>	321
<i>Add Floating Vertical Line</i>	322
<i>Add Free Vertical Curve</i>	323
<i>Vertical Discontinuity Check</i>	324
<i>Add Floating Vertical Line</i>	324
<i>Upcoming Vertical Assessment</i>	326
<i>Copy Elements</i>	327
<i>Add Free Vertical Curve</i>	328
<i>Add Fixed Vertical Line</i>	329
<i>Add Free Vertical Curve</i>	330
<i>Vertical Completion Checks</i>	331
<i>Vertical Alignment Annotation</i>	331
Chapter Challenge	332
Additional Exercises	332
<i>Side Road Vertical Layout</i>	332
<i>Vertical Alignment Layout Option 1</i>	332
<i>Vertical Alignment Layout Option 2</i>	332
<i>Previous Chapter Challenge Work</i>	332
Quiz Questions	332
2.7 Typical Sections	335
<i>TC Summary</i>	339
Chapter Prerequisites	339
Knowledge Prerequisites	339
Data Prerequisites	339
Files Needed	339
Hands On—Typical Sections	340
Opening a Typical Section Library	340
Creating a Typical Section Library	341
<i>TCs and the Intelligent DTM</i>	342
Template Walk-Thru	343
<i>Templates Tab</i>	343
<i>Layer Tab</i>	346
<i>Segment Tab</i>	348
<i>Mirror Tab</i>	352
<i>Superelevation Tab</i>	353
Template Construction	354
<i>New Template #1</i>	354
<i>New Template #2</i>	356
<i>Saving Templates</i>	356
Template Fine Points	357
<i>Preparation</i>	357
<i>Add Details Step by Step</i>	357
<i>Layer Naming</i>	357
<i>Multiple Passes</i>	358
<i>Independent Control Notes</i>	359
<i>Template Transitioning</i>	359
<i>Rules of Transitioning</i>	359

	<i>Layer Design</i>	364
	<i>Offset Layer Discussion</i>	364
	Cut/Fill Conditions	368
	Other Topics	369
	<i>Import Template from Graphics</i>	369
	<i>Copy Typical Sections</i>	369
	Chapter Challenge	371
	Additional Exercises	371
	Quiz Questions	371
2.8	Corridor Modeling	373
	Chapter Prerequisites	374
	Knowledge Prerequisites	374
	Data Prerequisites	374
	Files Needed	374
	Hands On—Corridor Modeling	374
	Opening the Data	375
	New Roadway Library	375
	The Project File	376
	Modeling Basics	379
	<i>Prerequisites</i>	379
	Defining the Roadway	379
	Project Scope	382
	Adding Roadway Entries	383
	<i>Roadway Entry Dialog</i>	384
	<i>Restarting Roadway Entries</i>	387
	<i>Continuing Roadway Entries</i>	388
	The Roadway Modeler	390
	<i>Main Tab</i>	391
	Advanced Tab	392
	<i>Upper Portion</i>	392
	<i>Middle Portion</i>	393
	<i>Lower Portion</i>	395
	<i>Final Set-up</i>	396
	Layer Controls Tab	397
	Running the Modeler	398
	Saving the Design	399
	Viewing Roadway Features	400
	Updating the Project File	401
	Chapter Challenge	402
	Additional Exercises	402
	Quiz Questions	403
2.9	Cross Sections	405
	Chapter Prerequisites	405
	Knowledge Prerequisites	405
	Data Prerequisites	406
	Files Needed	406
	Hands On—Cross Sections	406
	Creating Cross Sections	407
	Cross Section Viewer	409
	Create Cross Section—Main Tab	410
	<i>Cross Section Interval</i>	410
	<i>Surface Symbology</i>	413
	<i>Use Features Only</i>	414

Create Cross Sections—Controls Tab 415

Create Cross Sections—Features Tab 416

Crossing Features 416

Styles and Display 417

Show Features Outside 417

Create Cross Sections—Reports 418

Create Cross Sections—Symbology 419

Cross Section Spacing 420

Custom Cross Sections 421

Adding and Displaying New Features 422

Symbology Manager 423

Feature Style Manager 424

Adding Geometry to the DTM 424

Feature Properties 426

Drape Surface 427

Updating the Cross Sections Overview 428

Updating the Cross Sections 430

Display On 430

Refreshing 430

Cross Sections—Other Commands 431

Chapter Challenge **432**

 Additional Exercises 432

 Quiz Questions 433

Glossary **435**

Index **447**