

Full Contents

Section 1: Overview Essentials

1.1	Introduction	3
	Learning InRoads	3
	Basic Rules	3
	How to Use This Guide	4
	Section Breakdown	5
	<i>Section 1: Overview Essentials</i>	5
	<i>Section 2: Production Essentials</i>	5
	<i>Glossary</i>	5
	<i>Index</i>	5
	What's in a Chapter?	5
	Font Conventions	6
	<i>Italic</i>	6
	<i>Bold</i>	6
	<i>Bold and Italic</i>	7
	<i>Small Caps</i>	7
	<i>Underlined Small Caps</i>	7
	How to Use the CD	7
	Files on CD-ROM	7
	<i>Training Folders</i>	7
	<i>Training Files</i>	8
	<i>Chapter Files</i>	10
	Other CD Content	10
	Software Information	10
	AutoCAD versus MicroStation	10
	Version Compatibility	11
	Software File Paths	11
1.2	Orientation to InRoads	13
	Chapter Prerequisites	14
	The Bigger Picture	14
	InRoads versus CAD	15
	<i>The CAD Platform</i>	15
	<i>File Types</i>	15
	<i>InRoads and CAD</i>	16
	The InRoads Interface	17
	The Menu Bar	17
	The Workspace Bar	18
	The Feedback Pane	18
	Status Bar	19
	Toolbars	19
	The Surface Model	21
	Surface Origins	21
	Intelligent Models	22
	Surface Display	24

Geometry 25

 COGO Points 25

 Horizontal Alignments 25

 Vertical Alignments 27

 Event Points 27

Profiles 28

 Annotation 29

Typical Sections 30

 Backbone 30

 Cut and Fill Conditions 30

 Layers and Components 31

 Surface Intelligence 32

Roadway Models 32

 Express Modeler 33

 Roadway Designer 33

 Defining the Roadway 34

 Running the Modeler 34

 Superelevation 36

Cross Sections 38

 Custom Cross Sections 39

 Cross Section Viewer 40

 Annotation 40

 Cross Section Editing 40

Volumes 41

 Triangle Volume 41

 Grid Volume 41

 End-Area Volume 42

Reporting 42

 XML Reporting 43

Preferences 45

 Tools> Options 46

The Managers 46

 Symbology Manager 47

 Features - Style Manager 48

 Geometry - Style Manager 50

 Preference Manager 51

The Locks 52

 Write Lock 52

 Pen and Pencil 53

 Locate Lock 53

 Snap Lock 54

 Station Lock 55

 Report Lock 55

 Feature Filter 56

InRoads Support 56

 InRoads Help File 57

 Training 58

 Bentley 58

 Consultants 58

Chapter Challenge 58

 Quiz Questions 59

1.3	Sample Project Defined	61
	Preliminary Design Statement	61
	Project Design Criteria	61
	Scope of Work Details	62
	<i>Typical Sections</i>	63
	<i>Concept Sketches</i>	64
	<i>Design Criteria</i>	66
	<i>Project Vicinity Map</i>	68
1.4	Getting Going Now!	69
	Chapter Prerequisites	70
	Files Needed	70
	Hands On—Get Going Now!	71
	Hands-On—An Introduction	71
	Orientation	71
	Loading the Training Files	75
	<i>Preparing and Opening InRoads</i>	75
	<i>Project Defaults</i>	76
	<i>Creating a New Project Default Configuration</i>	79
	<i>Opening the Data</i>	80
	Lock Settings	81
	CAD File Preparation	81
	Surface Review and Display	82
	<i>Perimeter</i>	82
	<i>Contours</i>	83
	<i>Triangles</i>	85
	<i>Update 3-D/Plan Surface Display</i>	85
	<i>Surface Properties</i>	87
	<i>Feature Properties</i>	88
	<i>View Features</i>	90
	Horizontal Geometry File Creation	92
	<i>The Geometry Project</i>	92
	<i>Horizontal Alignment</i>	94
	<i>Vertical Alignment</i>	95
	Horizontal Geometry Workspace Bar Review	96
	<i>Workspace Bar Shortcuts - Review</i>	97
	<i>Workspace Bar Shortcuts - View</i>	98
	<i>View Stationing</i>	100
	<i>Alignment Stationing</i>	101
	<i>Horizontal Annotation</i>	103
	Profiling	106
	<i>Create Profile</i>	107
	Vertical Geometry Viewing	112
	<i>View Vertical</i>	112
	<i>View Vertical Annotation</i>	113
	Typical Sections	114
	<i>Templates</i>	115
	Roadway Modeling	118
	<i>Express Modeler</i>	118
	<i>Running the Express Modeler</i>	121
	Creating Cross Sections	124
	<i>Create Cross Sections</i>	124
	<i>Cross Section Viewer</i>	127
	Express Modeler and Cross Section Repetition	129

<i>Express Modeler Revisited</i>	129
<i>Cross Sections Revisited</i>	130
End-Area Volumes	131
<i>End-Area Volumes</i>	131
Chapter Challenge	135
Additional Exercises	135
Quiz Questions	135

Section 2: Production Essentials

2.1 Starting Up	139
Chapter Prerequisites	139
Knowledge Prerequisites	139
Data Prerequisites	139
Files Needed	139
Hands On—Starting Up	140
Selecting a CAD Platform	140
Starting InRoads	141
<i>InRoads Versus CAD</i>	141
The InRoads Interface	143
<i>The Menu Bar</i>	143
<i>The Workspace Bar</i>	144
<i>Workspace Bar Shortcuts</i>	146
<i>Active Data</i>	147
<i>Repositioning</i>	148
<i>The Feedback Pane</i>	149
Toolbars	150
<i>Standard Issue Toolbars</i>	150
<i>Modifying a Toolbar</i>	151
<i>Restoring Toolbar Defaults</i>	152
<i>Building a Custom Toolbar</i>	153
<i>Exporting and Importing Toolbars</i>	154
Project Defaults	155
<i>Creating a New Configuration</i>	155
Application Add-ins	157
Saving InRoads Data	158
Bentley Embedded Help	158
Exiting InRoads	159
Chapter Challenge	160
Additional Exercises	160
Quiz Questions	161
2.2 Settings, Styles and Symbology	163
Chapter Prerequisites	163
Knowledge Prerequisites	163
Data Prerequisites	163
Files Needed	164
Hands on — The Managers	164
<i>Managers Overview</i>	165
Using the Symbology Manager	166
<i>Using Named Symbology - Part 1</i>	168
<i>Using Named Symbology - Part 2</i>	170
<i>Using Named Symbology - Part 3</i>	171
Introduction to Intelligent DTMs	172

Style Manager - DTM Features	172
<i>Style - Surface Display</i>	175
Style Manager - Geometry	175
<i>Geometry Style - Details</i>	178
Creating a New Geometry Style	181
<i>General Information</i>	182
<i>Assigning Symbology</i>	182
<i>Assigning New Symbology</i>	185
<i>Defining the Settings</i>	188
Geometry Styles - Assigning	189
Preferences	191
<i>Preference Manager</i>	193
<i>Changing the Default Preference</i>	194
<i>Preferences Expanded</i>	195
Chapter Challenge	199
Additional Exercises	199
Quiz Questions	200
2.3 Surface Essentials	203
Chapter Prerequisites	203
Knowledge Prerequisites	203
Data Prerequisites	203
Files Needed	203
Hands On—Surface Essentials	204
Getting Started with Surfaces	204
<i>Starting Checks</i>	204
What is a DTM anyway?	205
DTM Basics	206
<i>Surface—New</i>	206
<i>The Basic DTM Point Types</i>	207
<i>Surface Properties</i>	208
The Existing Surface	209
<i>Feature Properties</i>	209
<i>The Three Feature Characteristics</i>	210
Introduction to the Locks	211
<i>The Write Lock</i>	211
<i>The Pencil Setting</i>	211
<i>The Pen Setting</i>	211
Surface Viewing	212
<i>Perimeter</i>	212
<i>Contours</i>	212
<i>Triangles</i>	213
<i>Update 3-D/Plan Surface Display</i>	213
<i>View Features</i>	214
Text Import Wizard - ASCII DTM Data	215
<i>Confirming Data Import</i>	224
<i>Processing Imported Surface Data</i>	225
<i>Viewing Imported Surface Data</i>	226
<i>Surface Import from Graphics, Utilities</i>	227
<i>Drape Surface, Utilities</i>	230
<i>Surface Import From Graphics, Contours</i>	233
DTM Data Viewing	236
Triangulation	237
<i>Triangulate Surface</i>	238

Saving Surfaces	240
Chapter Challenge	242
Additional Exercises	242
Quiz Questions	243
2.4 Horizontal Geometry	245
Chapter Prerequisites	245
Knowledge Prerequisites	245
Data Prerequisites	246
Files Needed	246
Hands On—Geometry	246
Project Scope Orientation	246
The Geometry Project File	247
<i>Opening Existing Geometry</i>	247
Existing Geometry—Examination	248
<i>Workspace Bar Assessment</i>	248
<i>Feedback Pane Assessment</i>	249
<i>Viewing Assessment—Preparation</i>	250
<i>View Horizontal Alignment</i>	251
<i>Point Symbolology</i>	251
<i>Review Horizontal Alignment</i>	254
<i>View Stationing</i>	255
<i>Viewing Assessment - Continued</i>	256
<i>Review Geometry Points</i>	258
<i>Horizontal Annotation—Cogo Points</i>	259
Horizontal Layout Discussion	262
<i>Layout Methods</i>	262
<i>Project Orientation</i>	263
Main Road Layout	263
Layout Option 1	263
<i>Creating Geometry</i>	264
<i>Saving Geometry</i>	265
<i>Horizontal Curve Set—Add PI</i>	266
<i>PI—Precision Key-in</i>	267
<i>Review/Save Horizontal</i>	268
<i>Horizontal Curve Set—Define Curve</i>	269
Layout Option 2	271
<i>Create/Edit Alignment by Cogo Points</i>	271
<i>Horizontal Alignment Annotation</i>	273
<i>Copy Geometry</i>	274
<i>Viewing Geometry</i>	275
<i>Delete Horizontal PI</i>	276
<i>Delete Horizontal Element</i>	277
<i>Alignment Discontinuity Check</i>	281
<i>Add Horizontal Free Curve</i>	282
<i>Defining the Beginning Station</i>	284
<i>View Stationing</i>	285
Layout Option 3	285
<i>Add Fixed Line</i>	286
<i>Add Horizontal Free Curve</i>	288
<i>Defining the Beginning Station</i>	289
<i>View Stationing</i>	289
<i>Copy Geometry</i>	289

Chapter Challenge	291
Additional Exercises	291
<i>Side Road Centerline Layout</i>	291
<i>Regression Deviation Check</i>	291
<i>Side Road Regression Check</i>	295
Quiz Questions	296
2.5 Profiling	297
Chapter Prerequisites	298
Knowledge Prerequisites	298
Data Prerequisites	298
Files Needed	298
Hands On—Profiling	298
Creating Profiles	299
Create Profile - General Leaf	301
<i>Set Name</i>	301
<i>Direction</i>	301
<i>Exaggeration</i>	301
<i>Surface Symbology</i>	302
Create Profile - Source Leaf	304
Create Profile - Controls Leaf	304
<i>Limits</i>	305
<i>Window Clearance</i>	305
Create Profile - Offsets Leaf	306
Create Profile - Include Leaf	307
<i>Crossing/Projected Features</i>	307
<i>Styles and Display</i>	307
<i>Bandwidth</i>	309
Create Profile - Symbology	310
Updating the Profile Overview	310
Updating the Profile	313
Profiles—Other Commands	314
Chapter Challenge	315
Additional Exercises	315
Quiz Questions	316
2.6 Vertical Geometry	319
Chapter Prerequisites	320
Knowledge Prerequisites	320
Data Prerequisites	320
Files Needed	320
Hands On—Vertical Geometry	320
Vertical Layout Discussion	321
<i>Layout Methods</i>	322
<i>Vertical Alignment Layout Prerequisites</i>	322
<i>The Project Orientation</i>	322
Creating New Vertical Geometry	324
Main Road Layout	325
Layout Option 1—Import from DTM	325
<i>Import Vertical from Surface</i>	326
<i>View and Review</i>	327
<i>View Vertical Annotation</i>	328
<i>Matching or Paralleling Existing Grade</i>	330
<i>Saving Vertical Alignments</i>	330
Layout Option 2—Vertical Curve Set	330

<i>VPI—Precision Key-in</i>	331
<i>Vertical Curve Set Tools</i>	331
<i>Preparation</i>	331
<i>VPI Dynamics</i>	332
<i>Vertical Curve Set – Add PI</i>	332
<i>Review Alignment</i>	334
<i>Adding More VPIs</i>	334
<i>Vertical Curve Set—Move PI</i>	335
<i>Vertical Curve Set – Insert PI</i>	337
<i>Vertical Curve Set—Define Curve</i>	338
<i>Move Curve PI</i>	339
<i>Completion Notes</i>	340
Layout Option 3—Vertical Element	340
<i>Update Profile</i>	342
<i>Element Command Overview</i>	342
<i>Vertical Starting Point</i>	343
<i>Add Fixed Vertical Line</i>	345
<i>Add Fixed Vertical Line</i>	347
<i>Add Free Vertical Curve</i>	349
<i>Add Fixed Vertical Curve</i>	350
<i>Vertical Alignment Discontinuity Check</i>	351
<i>Add Floating Vertical Line</i>	352
<i>Add Free Vertical Curve</i>	353
<i>Vertical Discontinuity Check</i>	354
<i>Add Floating Vertical Line</i>	354
<i>Upcoming Vertical Assessment</i>	356
<i>Copy Elements</i>	357
<i>Add Free Vertical Curve</i>	358
<i>Add Fixed Vertical Line</i>	359
<i>Add Free Vertical Curve</i>	360
<i>Vertical Completion Checks</i>	361
<i>Vertical Alignment Annotation</i>	361
Chapter Challenge	362
Additional Exercises	362
<i>Side Road Vertical Layout</i>	362
<i>Vertical Alignment Layout Option 1</i>	362
<i>Vertical Alignment Layout Option 2</i>	362
<i>Previous Chapter Challenge Work</i>	362
Quiz Questions	362
2.7 Typical Sections	365
Chapter Prerequisites	366
Knowledge Prerequisites	366
Data Prerequisites	366
Files Needed	366
Hands On—Typical Sections	367
Creating a Template Library	367
Opening a Template Library	370
Reviewing a Template Library	370
Viewing Templates	373
<i>View Controls</i>	375
Styles and the Intelligent DTM	376
Components	378
Components Expanded	380

Template Review	381
<i>Template CAD Display</i>	383
<i>Template Layers</i>	386
Component Constraints	389
<i>More on Constraints</i>	391
New Template #1	392
<i>New Template Placeholder</i>	392
<i>Template Section Details</i>	393
<i>Drag and Drop Insertion Point</i>	394
<i>Template Options</i>	395
<i>Last Minute Settings</i>	396
<i>Dragging and Dropping Components</i>	397
<i>Last Edit Undo / Redo</i>	399
<i>Component Mirroring</i>	399
<i>Template #1 Completion</i>	402
<i>Adding Cut / Fill Slopes</i>	404
<i>Component Merging</i>	407
<i>Constraint Release</i>	410
<i>End Condition Testing</i>	414
Create Template Command Summary	415
New Template #2	416
<i>Saving Templates</i>	416
Additional Template Topics	417
<i>Preparation</i>	417
<i>Add Details Step by Step</i>	417
<i>Multiple Passes</i>	418
<i>Independent Control Notes</i>	418
<i>Copy Typical Sections</i>	419
Chapter Challenge	420
Additional Exercises	420
Quiz Questions	420
2.8 Corridor Modeling	423
Chapter Prerequisites	424
Knowledge Prerequisites	424
Data Prerequisites	424
Files Needed	424
Hands On—Corridor Modeling	424
Opening Earlier Data	425
New Roadway Design File	425
Saving the Roadway Design File	426
The Project File	427
Modeling Basics	430
<i>Prerequisites</i>	430
The Roadway Designer	430
<i>Menu Commands</i>	430
<i>Corridor Management</i>	432
Project Scope	433
Adding Template Drops	435
<i>Continuing Template Drops</i>	437
End Condition Exceptions	438
Saving the Roadway Design File	440
Corridor Review	441
<i>Transition Bands</i>	442

<i>Connecting Transition #1 Points</i>	445
<i>Connecting Transition #2 Points</i>	448
Pre-Processing the Corridor	450
Create Surface	452
<i>Name and Preference</i>	453
<i>New Surfaces for Each Corridor</i>	453
<i>Empty Design Surface</i>	453
<i>Add Exterior Boundary</i>	454
<i>Densify Curves</i>	454
<i>Triangulate</i>	454
<i>Create Surface(s) from</i>	455
<i>Add Transverse Features</i>	455
<i>Display Features in Plan View</i>	456
<i>Final Set-up</i>	456
Creating the Design Surface	457
Surface Properties	459
Saving the Design Surface	461
Viewing Roadway Features	462
Updating the Project File	463
Chapter Challenge	465
Additional Exercises	465
Quiz Questions	465
2.9 Cross Sections	467
Chapter Prerequisites	467
Knowledge Prerequisites	467
Data Prerequisites	468
Files Needed	468
Hands On—Cross Sections	468
Creating Cross Sections	470
Cross Section Viewer	472
Create Cross Section—General Leaf	472
<i>Cross Section Interval</i>	473
<i>Surface Symbology</i>	476
<i>Use Features Only</i>	477
Create Cross Sections - Source Leaf	478
Create Cross Sections—Controls	478
Create Cross Sections—Include Leaf	479
<i>Crossing & Projected Features</i>	479
<i>Components</i>	480
<i>Styles and Display</i>	480
<i>Show Features Outside</i>	480
Create Cross Sections—Symbology	481
Cross Section Layout	481
Custom Cross Sections	483
Adding and Displaying New Features	484
<i>Symbology Manager</i>	485
<i>Style Manager</i>	487
<i>Adding Geometry to the DTM</i>	488
<i>Feature Properties</i>	490
<i>Drape Surface</i>	491
Updating the Cross Sections Overview	493
<i>Styles and Cross Sections</i>	495
Updating the Cross Sections	496

<i>Display On</i>	496
<i>Refreshing</i>	496
<i>Component Updating</i>	497
Cross Sections—Other Commands	498
Chapter Challenge	499
Additional Exercises	499
Quiz Questions	499
Glossary	501
Index	513