

Full Contents

Section 1: Overview Essentials

1.1	Introduction	3
	Learning InRoads	3
	Basic Rules	3
	How to Use This Guide	4
	Section Breakdown	5
	<i>Section 1: Overview Essentials</i>	5
	<i>Section 2: Production Essentials</i>	5
	<i>Glossary</i>	5
	<i>Index</i>	5
	What's in a Chapter?	5
	Font Conventions	6
	<i>Italic</i>	6
	<i>Bold</i>	6
	<i>Bold and Italic</i>	7
	<i>Small Caps</i>	7
	<i>Underlined Small Caps</i>	7
	How to Use the CD	7
	Files on CD-ROM	7
	<i>Training Folders</i>	7
	<i>Training Files</i>	8
	<i>Chapter Files</i>	10
	Other CD Content	10
	Software Information	10
	AutoCAD versus MicroStation	10
	Version Compatibility	11
	Software File Paths	11
1.2	Orientation to InRoads	13
	Chapter Prerequisites	14
	The Bigger Picture	14
	InRoads versus CAD	15
	<i>The CAD Platform</i>	15
	<i>File Types</i>	15
	<i>InRoads and CAD</i>	16
	The InRoads Interface	17
	The Menu Bar	17
	The Workspace Bar	18
	The Feedback Pane	18
	Status Bar	19
	Toolbars	19
	The Surface Model	21
	Surface Origins	21
	Intelligent Models	22
	Surface Display	24

Geometry	25
COGO Points	25
Horizontal Alignments	25
Vertical Alignments	27
Event Points	27
Profiles	28
Annotation	29
Typical Sections	30
Backbone	30
Cut and Fill Conditions	30
Layers and Components	31
Surface Intelligence	32
Roadway Models	32
Express Modeler	33
Roadway Designer	33
Defining the Roadway	34
Running the Modeler	34
Superelevation	36
Cross Sections	38
Custom Cross Sections	39
Cross Section Viewer	40
Annotation	40
Cross Section Editing	40
Volumes	41
Triangle Volume	41
Grid Volume	41
End-Area Volume	42
Reporting	42
XML Reporting	43
Preferences	45
Tools> Options	46
The Managers	46
Symbology Manager	47
Features - Style Manager	48
Geometry - Style Manager	50
Preference Manager	51
The Locks	52
Pen and Pencil	52
Locate Lock	53
Snap Lock	53
Station Lock	54
Report Lock	55
Feature Filter	55
InRoads Support	56
InRoads Help File	57
Training	57
Bentley	58
Consultants	58
Chapter Challenge	58
Quiz Questions	58
1.3 Sample Project Defined	61
Preliminary Design Statement	61
Project Design Criteria	61

Scope of Work Details	62
<i>Typical Sections</i>	63
<i>Concept Sketches</i>	64
<i>Design Criteria</i>	66
<i>Project Vicinity Map</i>	68
1.4 Getting Going Now!	69
Chapter Prerequisites	70
Files Needed	70
Hands On—Get Going Now!	71
Hands-On—An Introduction	71
Orientation	71
Loading the Training Files	75
<i>Preparing and Opening InRoads</i>	75
<i>Project Defaults</i>	76
<i>Creating a New Project Default Configuration</i>	79
<i>Opening the Data</i>	80
Lock Settings	81
CAD File Preparation	81
Surface Review and Display	82
<i>Perimeter</i>	82
<i>Contours</i>	83
<i>Triangles</i>	84
<i>Update 3-D/Plan Surface Display</i>	85
<i>Surface Properties</i>	87
<i>Feature Properties</i>	88
<i>View Features</i>	89
Horizontal Geometry File Creation	92
<i>The Geometry Project</i>	92
<i>Horizontal Alignment</i>	94
<i>Vertical Alignment</i>	95
Horizontal Geometry Workspace Bar Review	96
<i>Workspace Bar Shortcuts - Review</i>	97
<i>Workspace Bar Shortcuts - View</i>	98
<i>View Stationing</i>	100
<i>Alignment Stationing</i>	101
<i>Horizontal Annotation</i>	103
Profiling	106
<i>Create Profile</i>	107
Vertical Geometry Viewing	112
<i>View Vertical</i>	112
<i>View Vertical Annotation</i>	113
Typical Sections	114
<i>Templates</i>	115
Roadway Modeling	118
<i>Express Modeler</i>	118
<i>Running the Express Modeler</i>	121
Creating Cross Sections	124
<i>Create Cross Sections</i>	124
<i>Cross Section Viewer</i>	127
Express Modeler and Cross Section Repetition	129
<i>Express Modeler Revisited</i>	129
<i>Cross Sections Revisited</i>	130
End-Area Volumes	131

<i>End-Area Volumes</i>	131
Chapter Challenge	135
Additional Exercises	135
Quiz Questions	135

Section 2: Production Essentials

2.1 Starting Up	139
Chapter Prerequisites	139
Knowledge Prerequisites	139
Data Prerequisites	139
Files Needed	139
Hands On—Starting Up	140
Selecting a CAD Platform	140
Starting InRoads	141
<i>InRoads Versus CAD</i>	141
The InRoads Interface	143
<i>The Menu Bar</i>	143
<i>The Workspace Bar</i>	144
<i>Workspace Bar Shortcuts</i>	146
<i>Active Data</i>	147
<i>Repositioning</i>	148
<i>The Feedback Pane</i>	149
Toolbars	150
<i>Standard Issue Toolbars</i>	150
<i>Modifying a Toolbar</i>	151
<i>Restoring Toolbar Defaults</i>	152
<i>Building a Custom Toolbar</i>	153
<i>Exporting and Importing Toolbars</i>	154
Project Defaults	155
<i>Creating a New Configuration</i>	155
Application Add-ins	157
Saving InRoads Data	158
Bentley Embedded Help	158
Exiting InRoads	159
Chapter Challenge	160
Additional Exercises	160
<i>Variable Manager</i>	161
Quiz Questions	163
2.2 Settings, Styles and Symbology	165
Chapter Prerequisites	165
Knowledge Prerequisites	165
Data Prerequisites	165
Files Needed	166
Hands on — The Managers	166
<i>Managers Overview</i>	167
Using the Symbology Manager	168
<i>Using Named Symbology - Part 1</i>	170
<i>Using Named Symbology - Part 2</i>	172
<i>Using Named Symbology - Part 3</i>	173
Introduction to Intelligent DTMs	174
Style Manager - DTM Features	174
<i>Style - Surface Display</i>	177

Style Manager - Geometry	177
<i>Geometry Style - Details</i>	180
Creating a New Geometry Style	183
<i>General Information</i>	184
<i>Assigning Symbology</i>	184
<i>Assigning New Symbology</i>	187
<i>Defining the Settings</i>	190
Geometry Styles - Assigning	191
Preferences	193
<i>Preference Manager</i>	195
<i>Changing the Default Preference</i>	196
<i>Preferences Expanded</i>	197
Chapter Challenge	201
Additional Exercises	201
Quiz Questions	202
2.3 Surface Essentials	205
Chapter Prerequisites	205
Knowledge Prerequisites	205
Data Prerequisites	205
Files Needed	205
Hands On—Surface Essentials	206
Getting Started with Surfaces	206
<i>Starting Checks</i>	206
What is a DTM anyway?	207
DTM Basics	208
<i>Surface—New</i>	208
<i>The Basic DTM Point Types</i>	209
<i>Surface Properties</i>	210
The Existing Surface	211
<i>Feature Properties</i>	211
<i>The Three Feature Characteristics</i>	212
Introduction to the Locks	213
<i>The Pencil Setting</i>	213
<i>The Pen Setting</i>	213
Surface Viewing	214
<i>Perimeter</i>	214
<i>Contours</i>	214
<i>Triangles</i>	214
<i>Update 3-D/Plan Surface Display</i>	215
<i>View Features</i>	216
Text Import Wizard - ASCII DTM Data	217
<i>Confirming Data Import</i>	227
<i>Processing Imported Surface Data</i>	227
<i>Viewing Imported Surface Data</i>	228
<i>Surface Import from Graphics, Utilities</i>	229
<i>Drape Surface, Utilities</i>	232
<i>Surface Import From Graphics, Contours</i>	235
DTM Data Viewing	238
Triangulation	239
<i>Triangulate Surface</i>	240
Saving Surfaces	242
Chapter Challenge	244
Additional Exercises	244

Quiz Questions	245
2.4 Horizontal Geometry	247
Chapter Prerequisites	247
Knowledge Prerequisites	247
Data Prerequisites	248
Files Needed	248
Hands On—Geometry	248
Project Scope Orientation	248
The Geometry Project File	249
<i>Opening Existing Geometry</i>	249
Existing Geometry—Examination	250
<i>Workspace Bar Assessment</i>	250
<i>Feedback Pane Assessment</i>	251
<i>Viewing Assessment—Preparation</i>	251
<i>View Horizontal Alignment</i>	253
<i>Point Symbology</i>	253
<i>Review Horizontal Alignment</i>	257
<i>View Stationing</i>	259
<i>Viewing Assessment - Continued</i>	260
<i>Review Geometry Points</i>	261
<i>Horizontal Annotation—Cogo Points</i>	262
Horizontal Layout Discussion	265
<i>Layout Methods</i>	265
<i>Project Orientation</i>	266
Main Road Layout	266
Layout Option 1	266
<i>Creating Geometry</i>	267
<i>Saving Geometry</i>	268
<i>Horizontal Curve Set—Add PI</i>	269
<i>PI—Precision Key-in</i>	270
<i>Review/Save Horizontal</i>	271
<i>Horizontal Curve Set—Define Curve</i>	272
<i>Defining the Beginning Station</i>	274
<i>View Stationing</i>	275
Alignment Completion	276
<i>Import Geometry from Graphics</i>	277
<i>Completion Steps</i>	279
Chapter Challenge	280
Additional Exercises	280
Layout Option 2	280
<i>Create/Edit Alignment by Cogo Points</i>	280
<i>Horizontal Alignment Annotation</i>	282
<i>Copy Geometry</i>	284
<i>Viewing Geometry</i>	285
<i>Delete Horizontal PI</i>	286
<i>Delete Horizontal Element</i>	287
<i>Alignment Discontinuity Check</i>	291
<i>Add Horizontal Free Curve</i>	292
<i>Defining the Beginning Station</i>	294
<i>View Stationing</i>	294
Layout Option 3	295
<i>Add Fixed Line</i>	296
<i>Add Horizontal Free Curve</i>	298

	<i>Defining the Beginning Station</i>	299
	<i>View Stationing</i>	299
	<i>Copy Geometry</i>	299
	Side Road Centerline Layout	301
	Horizontal Regression	301
	<i>Regression Deviation Check</i>	301
	<i>Side Road Regression Check</i>	305
	Quiz Questions	306
2.5	Profiling	307
	Chapter Prerequisites	308
	Knowledge Prerequisites	308
	Data Prerequisites	308
	Files Needed	308
	Hands On—Profiling	309
	Creating Profiles	309
	Updating the Profile Overview	311
	Updating the Profile	314
	Profiles—Other Commands	315
	Chapter Challenge	316
	Additional Exercises	316
	Create Profile Settings	317
	Create Profile - General Leaf	317
	<i>Set Name</i>	317
	<i>Direction</i>	317
	<i>Exaggeration</i>	317
	<i>Surface Symbology</i>	318
	Create Profile - Source Leaf	320
	Create Profile - Controls Leaf	320
	<i>Limits</i>	321
	<i>Window Clearance</i>	321
	Create Profile - Offsets Leaf	322
	Create Profile - Include Leaf	323
	<i>Crossing/Projected Features</i>	323
	<i>Styles and Display</i>	323
	<i>Bandwidth</i>	325
	Create Profile - Symbology	326
	Quiz Questions	327
2.6	Vertical Geometry	329
	Chapter Prerequisites	330
	Knowledge Prerequisites	330
	Data Prerequisites	330
	Files Needed	330
	Hands On—Vertical Geometry	331
	Vertical Layout Discussion	332
	<i>Layout Methods</i>	332
	<i>Vertical Alignment Layout Prerequisites</i>	332
	<i>The Project Orientation</i>	333
	Main Road Layout	334
	Layout Option 1—Import from DTM	334
	<i>Import Vertical from Surface</i>	335
	<i>View and Review</i>	336
	<i>View Vertical Annotation</i>	337
	<i>Matching or Paralleling Existing Grade</i>	339

<i>Saving Vertical Alignments</i>	339
Creating New Vertical Geometry	339
Layout Option 2—Vertical Curve Set	340
<i>VPI—Precision Key-in</i>	341
<i>Vertical Curve Set Tools</i>	341
<i>Preparation</i>	341
<i>VPI Dynamics</i>	342
<i>Vertical Curve Set – Add PI</i>	342
<i>Review Alignment</i>	344
<i>Adding More VPIs</i>	344
<i>Vertical Curve Set—Move PI</i>	345
<i>Vertical Curve Set – Insert PI</i>	347
<i>Vertical Curve Set—Define Curve</i>	348
<i>Move Curve PI</i>	349
<i>Completion Notes</i>	350
<i>Vertical Alignment Annotation</i>	350
Chapter Challenge	351
Additional Exercises	351
<i>Side Road Vertical Layout</i>	351
<i>Vertical Alignment Layout Option 1</i>	351
<i>Previous Chapter Challenge Work</i>	351
Layout Option 3—Vertical Element	351
<i>Update Profile</i>	353
<i>Element Command Overview</i>	353
<i>Vertical Starting Point</i>	354
<i>Add Fixed Vertical Line</i>	356
<i>Add Fixed Vertical Line</i>	358
<i>Add Free Vertical Curve</i>	360
<i>Add Fixed Vertical Curve</i>	361
<i>Vertical Alignment Discontinuity Check</i>	362
<i>Add Floating Vertical Line</i>	363
<i>Add Free Vertical Curve</i>	364
<i>Vertical Discontinuity Check</i>	365
<i>Add Floating Vertical Line</i>	365
<i>Upcoming Vertical Assessment</i>	367
<i>Copy Elements</i>	368
<i>Add Free Vertical Curve</i>	369
<i>Add Fixed Vertical Line</i>	370
<i>Add Free Vertical Curve</i>	371
<i>Vertical Completion Checks</i>	371
<i>Vertical Alignment Annotation</i>	372
Quiz Questions	372
2.7 Typical Sections	375
Chapter Prerequisites	376
Knowledge Prerequisites	376
Data Prerequisites	376
Files Needed	376
Hands On—Typical Sections	377
Creating a Template Library	377
Opening a Template Library	380
Reviewing a Template Library	380
Viewing Templates	383
<i>View Controls</i>	385

Styles and the Intelligent DTM	386
Components	388
Components Expanded	390
Template Review	391
<i>Template CAD Display</i>	393
<i>Template Layers</i>	396
Component Constraints	399
<i>More on Constraints</i>	401
New Template #1	402
<i>New Template Placeholder</i>	402
<i>Template Section Details</i>	403
<i>Drag and Drop Insertion Point</i>	404
<i>Template Options</i>	405
<i>Last Minute Settings</i>	406
<i>Dragging and Dropping Components</i>	407
<i>Last Edit Undo / Redo</i>	409
<i>Component Mirroring</i>	409
<i>Template #1 Completion</i>	412
<i>Adding Cut / Fill Slopes</i>	414
<i>Component Merging</i>	417
<i>Constraint Release</i>	420
<i>End Condition Testing</i>	424
Create Template Command Summary	425
New Template #2	426
<i>Saving Templates</i>	426
Additional Template Topics	427
<i>Preparation</i>	427
<i>Add Details Step by Step</i>	427
<i>Multiple Passes</i>	428
<i>Independent Control Notes</i>	428
<i>Copy Typical Sections</i>	429
Chapter Challenge	430
Additional Exercises	430
<i>Template Basics Checklist</i>	431
Component Creation	432
Simple Components	432
<i>Preparation</i>	432
<i>Construction and Placement</i>	435
<i>Component Properties</i>	438
<i>Point Properties</i>	439
<i>Using a Simple Component</i>	442
<i>Simple Component - Template Review</i>	445
Workspace Bar Shortcut	448
Simple Components Continued	449
<i>Template Construction</i>	452
Template Points - Names	454
Constrained Component #1	457
<i>Component Curb Details</i>	458
<i>Component Construction</i>	459
<i>Component Review</i>	463
Unconstrained Components	465
<i>Unconstrained Component #2</i>	468
Component Construction	469
<i>Bike Path / Walkway</i>	469

End Conditions	470
<i>Fill Slope Creation</i>	470
<i>Set Dynamic Origin</i>	475
<i>Reset Dynamic Origin</i>	477
<i>Dynamic Origin Alert</i>	477
<i>Cut Slope Creation</i>	478
Building Template #1	479
<i>Template Drag and Drop</i>	480
<i>End Condition Testing</i>	482
<i>End Condition #3</i>	485
<i>Add Additional End Condition</i>	487
<i>End Condition Re-Test</i>	487
Building Template #2	488
Merging Components	488
Component Summary	489
<i>Component Types</i>	489
<i>Terminology</i>	489
<i>Component Concept #1</i>	490
More on Point Controls	490
Create Your Own	491
Quiz Questions	491
2.8 Corridor Modeling	493
Chapter Prerequisites	494
Knowledge Prerequisites	494
Data Prerequisites	494
Files Needed	494
Hands On—Corridor Modeling	494
Opening Earlier Data	495
New Roadway Design File	495
Saving the Roadway Design File	496
The Project File	497
Modeling Basics	500
<i>Prerequisites</i>	500
The Roadway Designer	500
<i>Menu Commands</i>	500
<i>Corridor Management</i>	502
Project Scope	503
Adding Template Drops	505
<i>Continuing Template Drops</i>	507
End Condition Exceptions	508
Saving the Roadway Design File	510
Corridor Review	511
<i>Transition Bands</i>	512
<i>Connecting Transition #1 Points</i>	515
<i>Connecting Transition #2 Points</i>	518
Pre-Processing the Corridor	520
Create Surface	522
<i>Name and Preference</i>	523
<i>New Surfaces for Each Corridor</i>	523
<i>Empty Design Surface</i>	523
<i>Add Exterior Boundary</i>	524
<i>Densify Curves</i>	524
<i>Triangulate</i>	524

<i>Create Surface(s) from</i>	525
<i>Add Transverse Features</i>	525
<i>Display Features in Plan View</i>	526
<i>Final Set-up</i>	526
Creating the Design Surface	527
Surface Properties	529
Saving the Design Surface	531
Viewing Roadway Features	532
Updating the Project File	533
Chapter Challenge	535
Additional Exercises	535
Superelevation Basics	536
<i>Fundamentals of Superelevation</i>	536
<i>Superelevation Slope Rate</i>	537
<i>Superelevation Transition Locations</i>	538
InRoads Superelevation	539
<i>AASHTO Wizard - Step 1, Criteria</i>	541
<i>Rate Calculator</i>	543
<i>AASHTO Wizard - Step 1 Revisited</i>	547
<i>AASHTO Wizard - Step 2, Definitions</i>	549
<i>AASHTO Wizard - Step 2 Revisited</i>	553
<i>AASHTO Wizard - Step 3, Controls</i>	556
<i>Point Controls</i>	559
<i>Deleting Conflicting Point Controls</i>	563
<i>Viewing the Superelevation</i>	564
<i>Editing the Superelevation - Rate</i>	567
<i>Editing the Superelevation - Transitions</i>	571
<i>Superelevation Rollover Locks</i>	573
<i>Superelevation Report</i>	579
<i>Creating the Surface DTM</i>	581
<i>Viewing the Superelevation Diagram</i>	583
<i>Superelevation Design Complexities</i>	590
<i>Use of Spirals</i>	590
Various Superelevation Related Tips	591
<i>Working with Superelevation Alternatives</i>	591
<i>Superelevation and Alignment Adjustments</i>	592
<i>Superelevation and Compound Curves Note</i>	592
Quiz Questions	592
2.9 Cross Sections	595
Chapter Prerequisites	595
Knowledge Prerequisites	595
Data Prerequisites	596
Files Needed	596
Hands On—Cross Sections	596
Creating Cross Sections	598
Cross Section Viewer	600
Adding and Displaying New Features	600
<i>Symbology Manager</i>	601
<i>Style Manager</i>	603
<i>Adding Geometry to the DTM</i>	604
<i>Feature Properties</i>	607
<i>Drape Surface</i>	607
Updating the Cross Sections Overview	609

Styles and Cross Sections 611

Updating the Cross Sections 612

Display On 612

Refreshing 612

Component Updating 613

Cross Sections—Other Commands 614

Chapter Challenge **615**

 Additional Exercises 615

 Create Cross Section—Settings 615

Cross Section Interval 616

Surface Symbology 619

Use Features Only 620

 Create Cross Sections - Source Leaf 621

 Create Cross Sections—Controls 621

 Create Cross Sections—Include Leaf 622

Crossing & Projected Features 622

Components 623

Styles and Display 623

Show Features Outside 623

 Create Cross Sections—Symbology 624

 Cross Section Layout 624

 Custom Cross Sections 626

 Quiz Questions 627

Glossary **629**

Index **641**