Full Contents

Section 1: Overview Essentials

1.1 Introduction 3
Learning InRoads Survey 3
Basic Rules 3
How to Use This Guide 4
Section Breakdown 5
Section 1: Overview Essentials 5
Section 2: Production Essentials 5
Appendices and Glossary 5
Index 5
What's in a Chapter? 5
Font Conventions 6
Italic 6
Bold 7
Bold and Italic 7
Small Caps 7
Underlined Small Caps 7
How to Use the CD 7
Files on CD-ROM 7
Training Folders 8
Training Files 8
Chapter Files 9
Other CD Content 9
Software Information 9
AutoCAD versus MicroStation 9
Version Compatibility 10
There are also intermediate releases that have not been listed here. 10
Software File Paths 11

1.2 Orientation to InRoads Survey 13
Chapter Prerequisites 14
The Bigger Picture 14
InRoads Survey vs. InRoads 14
The Purpose of InRoads Survey 14
InRoads Survey versus CAD 15
The CAD Platform 16
File Types 16
InRoads and CAD 17
Toolbars 18
The Fieldbook 19
The Style Manager 20
The Surface Model 20
Surface Origins 21
Intelligent Models 22
Surface Display 23

Geometry **24**
COGO Points 25
Horizontal Alignments 25
Vertical Alignments 26
Event Points 26
Profiles **27**
Volumes **28**
Grid Volume 28
Reporting **29**
XML Reporting 29
Preferences **30**
Tools> Options 31
Tools> Survey Options 32
The Managers **32**
Symbology Manager 32
Style Manager - Surfaces 34
Style Manager - Geometry 35
Preference Manager 35
The Locks **36**
The Locks and InRoads Survey 36
Pen and Pencil *36*
Report Lock *37*
InRoads Survey Support **37**
InRoads Help File 38
Training 38
Bentley 39
Consultants 39
Chapter Challenge **39**
Quiz Questions 40
Chapter As-Builts **41**
Quick Review 41

1.3 Sample Project Defined **43**
Preliminary Design Statement **43**
Project Design Criteria 43
Scope of Work Details 44
Concept Sketches *45*
Project Vicinity Map *47*

1.4 Getting an Overall Picture **49**
Chapter Prerequisites **49**
Knowledge Prerequisites 49
Data Prerequisites 50
Files Needed 50
Hands On—Getting an Overall Picture **50**
Loading the Training Files 51
Preparing and Opening InRoads Survey 51
The SelectCAD Platform *51*
Starting InRoads Survey *52*
Preparing to Run InRoads Survey 53
Project Defaults *53*
Creating a New Project Default Configuration *55*
The InRoads Survey Interface 56
The Menu Bar *56*
The Workspace Bar *56*

The Feedback Pane *57*
Status Bar *57*
New InRoads Survey Fieldbook 58
Raw Data 59
Sample raw data *59*
Loading a raw data file *59*
Target Height Alert *60*
Viewing the Collected Data 61
Toolbar *61*
CAD Viewing *61*
InRoads Survey Viewing *62*
The InRoads Survey Fieldbook 63
Stations *64*
Observations *65*
Importing Additional Raw Data 66
Viewing Imported RAW data *68*
Multiple InRoads Survey Fieldbooks 69
Deleting an InRoads Survey Fieldbook *70*
The Fieldbook Revisited 71
Importing Additional Raw Data *72*
More Fieldbook Work *73*
Survey Code Styles 73
Fieldbook Point Select *74*
Style Entries *75*
Feature Codes *76*
Feature Symbology *77*
Saving the InRoads Survey Fieldbook 80
The Purposes of InRoads Survey 81
Exporting a Surface Model 81
Surface Coding *81*
Survey Data to Surface *83*
Triangulating the Surface Data *84*
Viewing the Exported Surface *85*
Saving the Surface *87*
Exporting the Geometry Project 88
Survey Data to Geometry *89*
Reviewing the Geometry *89*
Saving the Geometry Project *91*
Ending off 92
Chapter Challenge 93
Additional Exercises 93
The Fieldbook Data *93*
The Surface Data *93*
The Geometry Data *93*
Quiz Questions 94
Chapter As-Builts 95
Quick Review 95

Section 2: Production Essentials

2.1 Getting Started 99
Chapter Prerequisites 99
Knowledge Prerequisites 99

Data Prerequisites 99
Files Needed 99
Hands On—Getting Started 100
Loading the Training Files 100
Starting Foundations 100
Selecting a CAD Platform 100
Starting InRoads 101
InRoads Survey Versus CAD 102
Preparing to Run InRoads Survey 103
Project Defaults 104
Creating a New Configuration 105
The InRoads Survey Interface 107
The Menu Bar 107
The Workspace Bar 109
Opening InRoads Survey Files 110
Workspace Bar Shortcuts 111
Active Data 113
Repositioning 114
The Feedback Pane 115
Toolbars 117
Standard Issue Toolbars 117
Modifying a Toolbar 119
Restoring Toolbar Defaults 120
Building a Custom Toolbar 120
Exporting and Importing Toolbars 122
Application Add-ins 123
Saving InRoads Data 124
Bentley Embedded Help 125
Survey Options 127
InRoads Options 128
Exiting InRoads 129
Chapter Challenge 130
Additional Exercises 130
Quiz Questions 131
Chapter As-Builts 132
Quick Review 132

2.2 The Style Manager 133
Chapter Prerequisites 133
Knowledge Prerequisites 133
Data Prerequisites 133
Files Needed 133
Hands On—The Feature Table 134
Starting InRoads Survey 134
Opening Previously Created Data 134
The Style Manager 135
Feature Codes 135
Feature Description 135
Feature Codes 137
Code Symbology 138
Coding Options 139
Feature Coding - Attributes 140
Looking at the Raw Data 140
Looking at the Fieldbook 141

Feature Code Attributes *142*
Adding Fieldbook Attribute Values *143*
Custom Operations 145
Survey Options *146*
Style Manager *147*
Control Codes 151
Importing Survey Data 153
Resolving Field Coding Errors *153*
Creating a New Fieldbook *153*
Importing Field Data *154*
Resolving Code Errors *155*
Logging Code Errors *158*
Continuing to Resolve Code Errors 160
Copying a Style *161*
Deleting a Fieldbook 165
Ending Off 166
Chapter Challenge 166
Additional Exercises 166
Reviewing Feature Codes *166*
Attribute Creation *166*
Custom Operations *166*
Fieldbook Work *167*
Quiz Questions 167
Chapter As-Builts 168
Quick Review 168

2.3 The Fieldbook 169
Chapter Prerequisites 169
Knowledge Prerequisites 169
Data Prerequisites 169
Files Needed 169
Hands On—The Fieldbook 170
Starting InRoads Survey 170
Opening Previously Created Data 170
The InRoads Survey Fieldbook 171
The Fieldbook Interface *171*
Fieldbook Editing Overview *173*
Importing Multiple Raw Data Files 174
Fieldbook Editing 178
Moving Code Info to Notes *178*
Deleting Extraneous Coding Entries *183*
Additional Fieldbook Editing *183*
Control Code Edits 184
View Settings *184*
Editing Start Codes *186*
Adding a Start Code *189*
NT Coding *192*
JPT Coding - Type 1 ..... *195*
JPT Coding - Type 2 ..... *196*
V8.02 Versus V8.05 Versus V8.09 Versus V8.11 Editing 199
Chapter Challenge 199
Additional Exercises 199
Quiz Questions 201

Chapter As-Builts **202**
Quick Review 202

2.4 Exporting the Fieldbook **203**
Chapter Prerequisites **203**
Knowledge Prerequisites 203
Data Prerequisites 203
Files Needed 203
Hands On—Exporting the Fieldbook **204**
Starting InRoads Survey 204
Opening Previously Created Data 204
Exporting Geometry 205
Survey Data to Geometry *205*
Reviewing the Geometry *206*
Saving the Geometry Project *208*
Selectively Exporting Geometry 209
The Survey Style Filter *210*
Activating a Survey Style Filter *211*
Exporting Geometry with a Filter *212*
Exporting a Surface Model 213
Surface Point Type Coding *213*
Survey Data to Surface *215*
Triangulating the Surface Data *217*
Surface Exporting Discussion *218*
Viewing the Exported Surface *219*
Locating Problem Areas 220
Potential Problem #1 220
Potential Problem #2 221
Redisplaying the Surface Triangles *223*
Viewing Surface Contours *223*
Potential Problem #3 224
Exporting the Surface *227*
Viewing the Surface *227*
Potential Problem #4 228
View Crossing Segments 230
Saving the Surface 232
Fieldbook to Graphics 233
View Settings *233*
Writing the Graphics to CAD *235*
Chapter Challenge **236**
Additional Exercises 236
Exporting Geometry *236*
Exporting the Surface *236*
Survey Data to Graphics *236*
Quiz Questions 237
Chapter As-Builts **238**
Quick Review 238

Appendices

A: Exterior Boundary Creation **241**
Chapter Prerequisites **241**
Knowledge Prerequisites 241
Data Prerequisites 241

Files Needed 241
Hands On—Creating an Exterior Boundary 242
Starting InRoads Survey 242
Opening Previously Created Data 242
CAD File Preparation 243
DTM Review 243
Reviewing Surface Triangles 245
The Surface Perimeter 250
CAD Clean-up 251
Working with the Delete Triangle Tool 252
Basic Procedure 252
Deleting Triangles - Setup 253
Deleting Triangles 254
View Perimeter 257
Re-Triangulation 258
Deleting Triangles 260
Viewing the Final Perimeter 261
Import Surface From Graphics 262
Surface Properties 264
Triangulate the Surface 265
Save the Surface 266

B: The InRoads Locks 267
Introduction 267
The Toolbar 267
Activation Timing 268
Lock Types 268
Lock Categories 269
Viewing and CAD-Related 269
Accessibility and InRoads-Related 269
Lock Presentation 269
InRoads Tagging 270
Ignoring 270
Removing 271
The Locks 272
Pen/Pencil Overview 272
The Pencil Setting 273
Usage Notes 273
The Pen Setting 274
Usage Notes 274
Delete Ink Lock 275
Usage Notes 275
Style Lock 276
Usage Notes 277
Locate Lock 278
Usage Notes 279
Snap Lock 280
Usage Notes 281
Station Lock 281
Usage Notes 282
Report Lock 282
Usage Notes 282
Feature Filter 283
Usage Notes 286

Cogo Audit Trail Lock 286
Top Ten Rules of the Locks 288

Glossary 289